

FloMAX Part Number Cross Reference

Standard Series Connectors

Dixon® Part #	Caterpillar® Part #	Wiggins Part #	FastFill
Engine Oil Nozzles			
ENBL	9S9273	OS2	N100
ENBL-P		OSP2	N100P
ENBL-PLUG	9S9274	0P-12	P100
ERJ		ON6	
Engine Oil Receivers			
ERS	9S9271	ON2	R100
ERS-C		ONC2A	R100C
ERS-CAP	9S9272	03B12P	C100
Coolant Fluid Nozzles			
CN	108-5455	EC280B8	N200
CN-P			N200P
CN-PLUG	108-5456	1209-8	P200
Coolant Fluid Receivers			
CR-S	IQ5459	EC285A8	
CR-C			R200C
CR-CAP	5P3587	1208-8	C200
Hydraulic Oil Nozzles			
HN	108-5433	6000B12	N300
HN-P			N300P
HN-PLUG		6009-12	P300
Hydraulic Oil Receivers			
HR	108-5454	6005A12	R300
HR-C			R300C
HR-CAP	IQ-5468	6008-12	C300
Transmission Fluid Nozzles			
TN	126-7538	C-1807	N400
TN-P			N400P
TN-PLUG		P-1844	P400
Transmission Fluid			
Receivers			
TR	108-5456	P-1804	R400
TR-C			R400C
TR-CAP	SP3587	P-1880	C400

Fuel Vent Series

	1 0001 1 0000				
Dixon Part #	Caterpillar® Part #	Wiggins Part #	FastFill		
VT	6G7803	ZV10	V150		
VT7		ZV10F	V150L7		
VT9		ZV10			
VTT	5V6106	ZV10C	V150C		
VT-C		ZV10A	V150A		
VT-A-7	9G01965	ZV11	V150D		
VT-A-9	4T1314	ZV11A			

R Series Connectors

Dixon Part #	Caterpillar® Part #	Wiggins Part #	FastFill
Engine Oil Nozzles			
R-EN		R15	N100R
R-EN-P			N100RP
R-EN-PLUG		R1507	P100R
Engine Oil Receivers			
R-ER		R16	R100R
R-ER-C			R100RC
R-ER-CAP		R1605	C100R
Coolant Fluid Nozzles			
R-CN		R11	N200R
R-CN-P			N200RP
R-CN-PLUG		R1107	P200R
Coolant Fluid Receivers			
R-CR		R12	R200R
R-CR-C			R200RC
R-CR-CAP		R1205	C200R
Hydraulic Oil Nozzles			
R-HN		R17	N300R
R-HN-P			N300RP
R-HN-PLUG		R1707	P300R
Hydraulic Oil Receivers			
R-HR		R18	R300R
R-HR-C			R300RC
R-HR-CAP		R1805	C300R
Transmission Fluid Nozzles			
R-TN		R13	N400R
R-TN-P			N400RP
R-TN-PLUG		R1307	P400R
Transmission Fluid Receivers			
R-TR		R14	R400R
R-TR-C			R400CR
R-TR-CAP		R1405	C400R

Diesel Fueling System

Dixon	Caterpillar®	Wiggins	E4E30	Shaw
Part #	Part #	Part #	FastFill	
Nozzles				
FN600		ZZF150	N150CP	
FN600BL		ZZ9A1	N150SL	
FN600B-PLUG				
Receivers				
FRS	2G9000	ZN2A	R150S	
FRS-C		ZNC2A	R150SC	
FRA		ZN2A	R150AL	
FRA-C		ZNC2A	R150ALC	
FR-CAP	0D0630	ZC20P	C150	388-4327
FR2	9D0630			
FR2-C				
FR2-R				
GFR-0		ZN6A	A150A	
GFR-45				
GFR-90		ZN6B	A150B	
GFR1-0		ZN6B		
GFR1-45				
GFR1-90		ZN6B		
FNS		ZS9	S150	
FNS2				
FN600S				
BFN		ZS5	28-N150B	
BH-F			FFF5C	
FNS10				
FR-SOCKET			R150SW	
BH-W			FFF4C	